



VLT® Automation Drive FC302

Recommended Drive settings for hoist applications with drive sw version 7.29 and higher






Analog In/Out

Par. Group 6-xx Analog In/Out: Because of the high variance how to use the analog i/O's for the different needs it is not part of this sheet. Both analog Inputs terminals 53 and 54 can select either voltage (-10 to 10V) or current (0/4-20mA). Remove power to the frequency converter before changing switch positions. Set switches A53 and A54 to select the signal type. U selects voltage, I selects current. The switches are accessible when the LCP has been removed. Note that some option cards available for the unit may cover these switches and must be removed to change switch settings. Always remove power to the unit before removing option cards.

Speed PID Controller

Special Functions

Incremental Encoder Interface



Autor: Peter Bohlender
Last date modified: Oct. 22. 2015
Version: 1.0